




**BEST AVAILABLE COPY** 









## BEST AVAILABLE COPY

| •   |   |                       | *                     |          |
|---|---|-----------------------|-----------------------|----------|
|   | er <sup>e e</sup>                             | i entre.              |                       |          |
| START 300   |   |                       | Τ;                    | 01       |
| Initialize Tube Handler R                           | , , , — <del>—</del>                          | mputer 302            | Fig.                  | OM       |
| Initialize Program Checks hardware status           | of Tube Handler                               | Robot 306             |                       |          |
| Hardware status ok?                                 | , <u>, , , , , , , , , , , , , , , , , , </u> | play error message on | computer t            | erminal  |
| 1308  |   |                       |                       | -        |
| YES   |   | 12                    |                       |          |
| Program prompts user for Work List is selected by u | i   |                       | 31 <i>4</i><br>ware ) |          |
| Work List validity status is                        |   | Display error msg. on |                       | terminal |
| 7 Z 3/6   |   | 2318                  |                       |          |
| Program prompts user to I                           | racks<br>oad travs of tube                    | s onto the Tube Handl | 320                   |          |
| User physically loads bar of platform               |   |                       |                       |          |
| Tray loading procedure:                             | J-324   |                       |                       | 322      |
|   |   |                       |                       |          |
|   | •   |                       |                       |          |





| Pick tube subroutine start \ 366   |     |
|--|-----|
| Tube Handler moves pick head to source tube location on Work List 363  |     |
| Pick head picks tube from tray 370   |     |
| Tube movement successfulNO Display error message on computer termi   | nal |
| 372 2376   |     |
| Yes 374 Fig. 80  |     |
| Pick tube subroutine end   |     |
| :  |     |
| Place tube subroutine start  Fig 8 E   |     |
| Pick head detects tubeNO Display error message on computer terminal  |     |
| 7 380  |     |
| Yes (394)  |     |
| Tube Handler moves pick head to target tube location on Work List Pick head places tube into tray 386  |     |
| Tube movement successfulNO> Display error message on computer termin   | nai |
| 338  |     |
| Yes  |     |
| Place tube subroutine end $\sim$ 390   |     |
| The state of the s |     |

.

|     | 2D scan tube subroutine start 394 Fig 8F   |  |
|-----|--|--|
|     | Pick head detects tube >NO Display error message on computer terminal  |  |
|     | 396  |  |
| •   | Yes  |  |
|     | Tube Handler moves pick head to camera or scanner module location 5402 Camera or scanner is activated to capture image of 2D code marked on tube |  |
|     | Tube movement successfulNO→ Display error message on computer terminal   |  |
| •   | YES (404)  |  |
| . * | 2D scan tube subroutine end 408  |  |
|     | Export tube subroutine start  Fig. 86  414   |  |
| ~   | Pick head detects tube Display error message on computer terminal  |  |
|     | Yes  |  |
|     | Tube Handler moves picks head to export location 418 420   |  |
|     | Export location module transports tube from platform of current tube handler robot to external tube handler robot                                |  |
|     |  |  |
|     |  |  |
|     |  |  |

Tube movement successful NO-Display error message on computer terminal

Yes

Fig 8 H

Export tube subroutine end 426